



iRobot Roomba Cleaning Head Module

How to install your new Cleaning Head Module


1 Remove Roomba's side brush screw.




2 Remove Roomba's side brush.




3 Unscrew the four screws shown below and remove Roomba's bottom cover.




4 Remove the four screws that retain Roomba's cleaning head module.



5 Remove Roomba's storage bin.



6 Remove Roomba's cleaning head module.



7 Install Roomba's new cleaning head module.

8 Replace the four screws that retain the new cleaning head module.

9 Replace the storage bin.

10 Replace Roomba's bottom cover and the 4 screws that retain the bottom cover.

11 Replace Roomba's side brush and side brush screw.

For further assistance, please visit the Customer Support section of our website at www.irobot.com.